

| Wiring<br>color code.<br>wire harness | 67 Lincoln TURN signal switch |  |
|---------------------------------------|-------------------------------|--|
| # 5                                   | orange - blue stripe          | RH tail lamp TURN + stop                                     |
| # 9                                   | green - orange stripe         | LH tail lamp TURN + stop                                     |
| # 362                                 | Red                           | RH TURN indicator on dash.                                   |
| # 363                                 | yellow                        | LH TURN indicator on dash                                    |
| # 694                                 | Brown.                        | To turn signal relay - <u>not used</u><br><u>any more</u> !! |
| # 511                                 | green                         | to brake light switch  |
| # 2                                   | white - blue stripe           | RH Front TURN + park   |
| # 3                                   | green - white stripe          | LH Front TURN + park   |
| # 44                                  | Blue                          | to warning indicator relay.                                  |
| # 482 A                               | Blue - yellow stripe          | to Horns   |
| # 460 A                               | yellow                        | : power to horn switch from 30A<br>circuit breaker.          |
| # 385                                 | white - red stripe            | to turn signal relay and<br>emergency Flasher.               |
| PRNDL<br>light                        | Blue - red stripe             |  |

The Lincoln / MERCURY  
Old Parts Store  
2040A Gentry Street  
Clearwater, FL 33765